




QCKALA
021-71053889
09108904005


ADJUSTABLE FILLET WELD GAUGE

WITH UNEQUAL LEG MEASUREMENT FEATURE

STANDARD
OR METRIC



G.A.L. Adjustable Fillet Weld Gauge is easy to use.



To measure fillet welds place irregular curve edge flush to horizontal toe of weld so the straight edge is in line with the horizontal member.



To measure weld throat thickness place the 45° angle end flush to the horizontal and vertical members. Loosen the thumb screw and slide the pointer until it touches the face of the weld.

CAT 3

NDT Supply.com, Inc.
7952 Nieman Road
Lenexa, KS 66214-1560 USA

Phone: 913-685-0675, Fax: 913-685-1125
e-mail: sales@ndtsupply.com, www.ndtsupply.com

